Practical -7

Aim: Implement a Wireless sensor network simulation.

Basic setup
















1: Create the following network using AccessPoint-PT-A and PC-PT.

- 2: Click on PC0 Physical tab.
- 3: Turn off the CPU (off green arrow) and remove the FastEthernet module (removing place in red arrow) and install PT-HOST-NM-1W-A (blue arrow) and turn On the CPU.

Note: when ON yellow light will glow above red on/off button.




- 4. A connection will be made between Accesspoint and PC0
- 5. Click on PC1 and click on physical tab.
- 6. Repeat step 3 and see if the connection is done between PC1 and Accesspoint.

Now similarly for laptop


- 7. Click on Laptop Physical tab.
- 8. Turn off the Laptop (off green arrow) and remove the PT-LAPTOP-NM-1CFE module (removing place in red arrow) and install PT-LAPTOP-NM-1W (blue arrow) and turn On the Laptop.

A connection will be made between Accesspoint-PT-N and Server




Now similarly for server

- 9. Click on Server and click on Physical tab.
- 10. Turn off the Server (off green arrow) and remove the PT-HOST-NM-1CFE module (removing place in red arrow) and install PT-HOST-NM-1W (blue arrow) and turn On the Server.




A connection will be made between Accesspoint-PT-N and Server.

After these stes the setup looks like:



11. Click on PC0 ——— Desktop ——— IP Configuration & set the IP config: Select both the static options & give IP Address as 10.1.1.1




Similarly for PC1

12. Click on PC1 — Desktop — IP Configuration & set the IP config: Select both the static options & give IP Address as 10.1.1.2

Similaly for laptop

13. Click on Laptop —— Desktop—— IP Configuration & set the IP config: Select first option as **static** for IP configuration & give IP Address as 10.1.1.3\
Select second option **Auto Config** for Ipv6 Configuration.



Similarly for server

14. Click on server ——— Desktop ——— IP Configuration & set the IP config:

Select both the static options & give IP Address as 10.1.1.4


15. Testing connections:

Test Access PointA

a. Ping PC1 (10.1.1.2) from PC0. The ping should succeed.

To Ping click on PC0 ——— Desktop ——— Command prompt

Write command: ping 10.1.1.2



b. Ping Laptop0(10.1.1.3) and Server0 (10.1.1.4) from PC0. The pings should fail.

Similarly on the same terminal write the commands:

ping 10.1.1.3

ping 10.1.1.4

```
PC0
                                                                            X
 Physical
            Config Desktop Programming
                                                Attributes
   Command Prompt
                                                                                    Χ
   :\>ping 10.1.1.3
  Pinging 10.1.1.3 with 32 bytes of data:
  Request timed out.
  Request timed out.
  Request timed out.
Request timed out.
  Ping statistics for 10.1.1.3:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
  C:\>ping 10.1.1.4
  Pinging 10.1.1.4 with 32 bytes of data:
  Request timed out. Request timed out.
   Request timed out.
  Request timed out.
  Ping statistics for 10.1.1.4:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
  C:\>
Тор
```

16.Test Access PointN

a.Ping Server0 (10.1.1.4) from Laptop0. The ping should succeed.

To Ping click on Laptop ——— Desktop ——— Command prompt


Write command: ping 10.1.1.4

b. Ping PC0 (10.1.1.1) and PC1 (10.1.1.2) from Laptop0. The pings should fail.

Similarly on the same terminal write the commands:

ping 10.1.1.1

ping 10.1.1.2




Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 17ms, Maximum = 47ms, Average = 30ms C:\>ping 10.1.1.1 Pinging 10.1.1.1 with 32 bytes of data: Request timed out. Request timed out. Request timed out. Request timed out. Ping statistics for 10.1.1.1: Packets: Sent = 4, Received = 0, Lost = 4 (100% loss), C:\>ping 10.1.1.2 Pinging 10.1.1.2 with 32 bytes of data: Request timed out. Request timed out. Request timed out. Request timed out. Ping statistics for 10.1.1.2: Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),


Top

C:\>

- 17. Now Turn off the port of AccesspointN
- a. Turn on Port1 on Access Point3 and turn off Port1 on Access PointN. Laptop0 and Server0 should associate with Access Point3.

To turn off/on you need to select the access point & then go to config then click on port1 & also maximize the window.





Lastly ping server (10.1.1.4) from laptop using command:

Ping 10.1.1.4

Ping will be successful